


# VERSION 2019

Instruction machine control  
RondoDry



We are Fliegl.

english

 [www.fliegl.com](http://www.fliegl.com)

Dok. Nr. 2-103B07181.0  
Vers. 1.0 St. 07/2018


## start page



## start page

The start page appears after commissioning the controller. This symbol shows that the control is active (symbol rotates). If the symbol does not move, a restart of the control is necessary. The "Step" field always contains the currently active step from the step sequence or the current state. By pressing the "home button" the user gets to the main page. With the "Back button" the user gets back one level. The "control active" symbol, the "home key", the "back key" and the "step" field are multiple used elements that always have the same meaning.

## Home




## Home

The following elements are shown on the main page:

- + current step
- + last accumulated message including time stamp
- + an overview of the system with current measured values (reduced view).
- + Alarms
- + Operating mode
- + Settings
- + Basic settings
- + HAND
- + AUTOMATIC

\$R \$Clicking this button takes you to the corresponding subitem.

: This icon indicates that an alarm is currently active.



## alarms

The "Alarms" page lists all active, unacknowledged alarms.

Through pressing the "Inverter reset" button, a reset of the frequency inverter for the lattice drum motor is carried out.


Touch the "Acknowledge Alarms" button, the active alarms are reset. Alarms are acknowledged if they can be acknowledged.

The "History" button is used to display the active and past acknowledged alarms

S	report	State	active	Inactive	Approved
0		Fault inverter drum	Normal	26.02.2019 21:19:55	26.02.2019 21:20:04
1		Fault i550 Ethercat	Normal	26.02.2019 21:19:41	26.02.2019 21:19:45
2		overfill protection	Normal	26.02.2019 21:19:41	26.02.2019 21:19:45
3		Fault EL2008 PLC6	Normal	26.02.2019 21:19:41	26.02.2019 21:19:45
4		Fault EL2008 SPS7	Normal	26.02.2019 21:19:41	26.02.2019 21:19:45
5		Fault EL3202 SPS8	Normal	26.02.2019 21:19:41	26.02.2019 21:19:45
6		Fault EL1008 PLC4	Normal	26.02.2019 21:19:41	26.02.2019 21:19:45
7		Fault EL1008 SPS5	Normal	26.02.2019 21:19:41	26.02.2019 21:19:45
8		Fault EK1100 PLC2	Normal	26.02.2019 21:19:41	26.02.2019 21:19:45
9		Fault EL1008 PLC3	Normal	26.02.2019 21:19:41	26.02.2019 21:19:45
10		Emergency stop	Normal	26.02.2019 21:19:41	26.02.2019 21:19:45
11		Undertemperature limit	Normal	26.02.2019 09:39:01	26.02.2019 09:39:57


## Alarms history

Under "History" the last 200 alarms with timestamp and status are listed.




## operation mode

Under "Operating mode", you can choose between the operating modes "OFF", "Automatic" and "Manual".  
The corresponding operating mode is activated by touching the button.  
If manual mode is activated, the individual actuators can be overridden. Use the "Hand" button (main page). The HAND mode must not be used for maintenance. The mode HAND is automatically exited after a certain time, then all actuators go to "\$OFF". RISK OF INJURY!!!



## Overview

The overview shows the actual and set values of the controller.




## hand

If the "Manual" operating mode is active, pressing the switch opens and closes the corresponding actuator, or switches it on and off. A setpoint is specified via the "Setpoint" buttons. The "All Off" button is used to set the desired actuator "All drives are switched off and slide closed."

When operating mode "Automatic" or "Off" is active, pressing the button has no effect.


: No protective devices are active on the software side in manual mode.



## automatic

Here the actual values are shown. The "Odur Mode" and "Normal Mode" areas indicate which mode is currently active in automatic mode.

Coad setting for the automatic mode can be made under "Main Menu Settings."




Fliegl  
AGRARTECHNIK

## hand

If the "Manual" operating mode is active, pressing the switch opens and closes the corresponding actuator, or switches it on and off. A setpoint is specified via the "Setpoint" buttons. The "All Off" button is used to set the desired actuator "All drives are switched off and slide closed."

When operating mode "Automatic" or "Off" is active, pressing the button has no effect.

: No protective devices are active on the software side in manual mode.



## hand frame

The other points are reached by scrolling down.

## settings

The screenshot shows the 'settings' menu of a Fliegl Agrartechnik control panel. It lists several parameters with their current values and available options:

1. drum	0 Hz 0 W	50 Hz
2. Setpoint fans	29.40 °C	100.00 °C
3. Setpoint heating pump	14.43 °C	100.00 °C
4. flushing intervals	0	40
5.1 flushing duration		T#2m
5.2 flushing time when Emptying		T#1m
odour mode		
6. Speed fans		350.00 rpm

Navigation icons for back, home, and menu are at the top left, and scroll buttons are on the right.

## settings

## basic settings

The screenshot shows the 'basic settings' menu of a Fliegl Agrartechnik control panel. It lists several configuration items:

- 1. curves
- 2. parameter drum
- 3. Controller fans
- 4.1 Heating pump controller
- 4.2 Parameter heat meter

Navigation icons for back, home, and menu are at the top left, and scroll buttons are on the right.

## basic settings

# settings

1. drum	0 Hz 0 W	50 Hz
2. Setpoint fans	29.40 °C	100.00 °C
3. Setpoint heating pump	14.43 °C	100.00 °C
4. flushing intervals	0	40
5.1 flushing duration		T#2m
5.2 flushing time when Emptying		T#1m
odour mode		
6. Speed fans		350.00 rpm
7. Time reduced speed		T#0ms
Weights (net)		
8. full weight		3000 kg
9. emptying weight		2000 kg
10. Empty weight		1000 kg
Timers	min	Max
11. Filling	T#1s	T#30s
12. Drying	T#1s	T#30s
13. Emptying	T#1s	T#30s
Valve		
14. Monitoring time limit positions		T#2s500ms
14.1 Monitoring time external		T#2s500ms
15. Time delay to pump		T#5s
16.1 Time emergency run		T#1h
16.2 Time emergency run caster ramp		T#1m
17. Maximum time hand active		T#15m
18. Maximum time login		T#5m
19. Folder log files		batch1

1. Sets the drum rotation frequency
2. Specifies the setpoint for heat dissipation by the fans.
3. Specifies the setpoint for the control of the heating circulating pump.
4. Sets after how many filling and draining cycles a flushing process takes place.
5. Sets the amount of time that will be flushed.
6. Sets the fan speed at which the fans run during the odor mode.
7. Sets the amount of time the fans are in the odor mode at reduced speed to run.
8. Sets the full weight.
9. Sets the draining weight.
10. Sets the curb weight.
11. Sets the maximum time for the filling process.
12. Sets the maximum time for the evaporation process.
13. Sets the maximum time for the draining process.
14. Sets the monitoring time for reaching the end position of the slide valves
15. Sets the time delay between reaching the end position and pump release
16. Sets the length of time during which the system enters the operating mode "emergency operation".
17. Sets the maximum time for the manual mode.
18. Sets the maximum time for login (user).
19. Folder for log files



- 1. curves
- 2. parameter drum
- 3. Controller fans
- 4.1 Heating pump controller
- 4.2 Parameter heat meter



## basic settings frame

The other points are reached by scrolling down.

- 1. curves
- 2. parameter drum
- 3. Controller fans
- 4.1 Heating pump controller
- 4.2 Parameter heat meter
- 5. Parameter weighing system
- 6. Overflow correction, filling
- 7. Overflow correction, emptying
- 8. Overflow correction, Drying
- 9. Under temperature protection
- 10. Temperature readings
- 11. Options
- 12. Set / load default values
- 13. Language switching
- 14. Other
- 15. Functions



- 1. System Info
- 2. measurement
- 3. Login
- 4. Maintenance counter
- 6. Leak test



- 1. System Info
- 2. measurement
- 3. Login
- 4. Maintenance counter
- 6. Leak test
- 7. Datalogger
- 8. Browser
- 11. Time

## 14. Other frame

The other points are reached by scrolling down.



- 1. Warning counter
- 2. User administration
- 3. step chain J1939 Manager
- 4. J1939 manager
- 5. Flick
  
- 1. Warning counter
- 2. User administration
- 3. step chain J1939 Manager
- 4. J1939 manager
- 5. Flick
- 6. Touches
- 7. step user level
- 8. User level
- 9. inputs
- 10. sequence blinker
- 11. blinker
- 12. sequence expiration
- 13. Sequence operating mode
- 14. Device Reader
- 15. alarms
- 16. Alarms detail
- 17. Alarms history
- 18. sequence leak test
- 19. Curves
- 20. USB
- 21. Data logger SAVE DATA

## 15. Functions frame

The other points are reached by scrolling down.

## 1. curves

1. curves


2. Min Max Timestamps

4. New Data Written



**Fliegl**  
AGRTECHNIK

## 2. parameter drum




**Fliegl**  
AGRTECHNIK

## 5. Parameter weighing system

total weight		5911 kg	Zero weighing system		400
Load cell	version	serial number	value	Raw	Offset
1	2.18	16120026.0	1324	1424	100
2	2.18	16120006.0	1867	1967	100
3	2.18	13060228.0	2301	2401	100
4	2.18	16120155.0	419	519	100

**Fliegl**  
AGRTECHNIK

## 9. Under temperature protection



**Fliegl**  
AGRTECHNIK

## 1. curves

Curves graphically displays the recorded values of the listed sensors or loads.

## 2. parameter drum

Min and max limit the setpoint input in manual mode and automatic mode.

## 5. Parameter weighing sys

Used to adjust the load cells.

Valve zero:

Z.B. every half year (see maintenance / care interval list, see maintenance counter), the weighing system must be zeroed by the operator. The device must be completely empty and clean for this purpose.

The adjustable values for the individual load cells are set by Fliegl at the factory or at startup.

## 9. Under temperature prote


Undertemperature limit can be set under "Undertemperature protection." When the set low temperature is reached, the low temperature protection becomes active.

Both the supply air (ambient air) and the set low temperature limit value are displayed in the curve below the "Undertemperature protection" overview R \$N \$RN.

The operator is responsible for frost protection. The equipment regulations of the heat exchanger manufacturer must be adhered to. Should no heat be left on the dryer for an extended period of time, it is recommended that the system be completely emptied (liquid manure and heating water).

Scroll down to see the outside temperature during the day

## 6. Overflow correction, filling




## 6. Overflow correction, filling

The "Overrun Correction" is used to compensate for the overflow of the filling pump

The controller detects the weight of the material that was filled in by the overrun (difference to the setpoint "full weight").

The deviations are recorded per cycle and from this the average of the last 10 cycles is formed. The overrun correction causes correspondingly less material to be filled in to correct the amount that has been filled too much by the overrun.


## 7. Overflow correction, emptying



## 7. Overflow correction, emptying

Like "Overrun Correction", only for the emptying process.

## 8. Overflow correction, Drying



## 8. Overflow correction, Drying

Like "Overrun Correction", only for the drying process.

### 3. Controller fans

KP	10.0	Proportional factor (Kp)
TN	20.0	Reset time (Tn)
TV	0.0	Retention time (Tv)
min	1.0	min
Max	950.0	Max

## 3. Controller fans


Here, the control parameters for the PID controller of the fans can be set.

KP	10.0	Proportional factor (Kp)
TN	20.0	Reset time (Tn)
TV	0.0	Retention time (Tv)
min	1.0	min
Max	950.0	Max


## 3. Controller fans frame

It is recommended to change the factory settings or the default values set by the Fliegl installation engineer only in consultation with the local heating engineer.

100.0	ACTUAL	Y - 1.0
29.2	SET_POINT	LIMITS_ACTIVE - TRUE
10.0	KP	OVERFLOW - FALSE
20.0	TN	
0.0	TV	
0.0	Y_MANUAL	
0.0	Y_OFFSET	
1.0	Y_MIN	
950.0	Y_MAX	
FALSE	MANUAL	
FALSE	RESET	




## 4.1 Heating pump controller





## 4. Controller heating pump

Here, the control parameters for the PID controller of the heating circulating pump can be set.



## 4. Controller heating pump frame

It is recommended to change the factory settings or the default values set by the Fliegl installation engineer only in consultation with the local heating engineer.



## 10. Temperature readings

Temperature is:

Heat meter input	14.43 °C
Heat meter output	15.56 °C
feed air sensor PT100	8.00 °C
System return PT100	29.20 °C



## 10. Temperature readings

Shows the current ACTUAL measured values of the temperature sensors installed in the system.

## 11. Options



<input checked="" type="checkbox"/> Heat meters	<input checked="" type="checkbox"/> Libra
<input checked="" type="checkbox"/> heat pump	<input checked="" type="checkbox"/> Load cell 1
<input checked="" type="checkbox"/> Air scrubber	<input checked="" type="checkbox"/> Load cell 2
	<input checked="" type="checkbox"/> Load cell 3
	<input checked="" type="checkbox"/> Load cell 4



## 11. Options

Individual system components can be selected and deselected under the menu item "Options."

The load cells can be individually selected and deselected

To select or deselect one of the options, the gray field must be pressed to operate the touch display + select the boxes (operation via multitouch).

Should the operation be done with a mouse over a computer screen, the gray area can be permanently switched on via the switch I / O.

## 12. Set / load default values



Load defaults F12345_AU-12345_PR-D12345678_Muster.ini	
Reset default values F12345_AU-12345_PR-D12345678_Muster_STD.ini	
Load factory settings reboot required	

## 12. Set / load default value

The default values can be reset or loaded under this menu item. It is also possible to reset to the factory settings, this requires a reboot.

## 13. Language switching




english  
english  
en




## 13. Language switching

The operating language can be set under this menu item.



## 14. Other



## 15. Functions

## 1. System Info

The screenshot shows the 'System Info' screen of the Fliegl Agrartechnik control panel. It displays various system parameters and project details. On the left, there is a list of parameters: System time (2019-02-26 21:23:29), project information, project name, Creation Date (26.2.2019), Filename (oDrySP14\_JANZTEC\_.Vilsmeier.3), Chassis NR. (F12345), Order number (AU-12345), Customer (Muster), and Version (1.0.0.0). Below this, a note states 'The smallest revision of the working copy.' followed by 'MINREVISION' and '25228'. At the bottom right of the screen, there are navigation icons: a left arrow, a house icon, a zero symbol, an up arrow, an equals sign, and a down arrow.

## 1. System Info

Under "System info" basic information about the drying system is stored.

## 2. measurement

The screenshot shows the 'Measurement' screen. It displays current measurements: Total weight (5912 kg) and Heat (118.620 kWh). Below these values are three buttons: 'Measurement start', 'Measurement stop', and 'reset'. Navigation icons are located at the top right: a left arrow, a house icon, a zero symbol, an up arrow, an equals sign, and a down arrow.

## 2. measurement

Under "Measurement" a measurement can be started during an evaporation step.

## 3. Login

The screenshot shows the 'Login' screen. It lists user levels: 0 (standard users), 1 (Master user), 2 (Administrator), and 3 (Super administrator). A red button labeled 'Change user level' is present. Below it, a black bar shows the 'Current user level' as '0 standard users'. Navigation icons are at the top right: a left arrow, a house icon, a zero symbol, an up arrow, an equals sign, and a down arrow.

## 3. Login

Under "Login" the user level can be changed by entering a password.

## 4. Maintenance counter

The screenshot shows the 'Maintenance counter' screen. It displays seven maintenance counters: Hour meter (21d06:22:09, 56), Maintenance counter 1 (21d06:22:09, 56, reset), Maintenance counter 2 (21d06:22:09, 56, reset), Maintenance counter 3 (21d06:22:09, 56, reset), Maintenance counter 1 (50d00:00:00, Maximum), Maintenance counter 2 (100d00:00:00, Maximum), and Maintenance counter 3 (730d00:00:00, Maximum). Navigation icons are at the top right: a left arrow, a house icon, a zero symbol, an up arrow, an equals sign, and a down arrow.

## 4. Maintenance counter

The "Maintenance counter" shows the elapsed time since the last reset.

The operating hours counter runs from the initial startup of the device (factory test).

The maintenance counters 1 - 3 can be used for maintenance, servicing and maintenance be set.

## 5. USB

acc 1	chgrp fliegl -R /media/sdcard/data/ ---	c 0	r 22
acc 2	chmod g+s -R /media/sdcard/data/ ---	c 0	r 22
acc 3	chmod 775 -R /media/sdcard/data/ ---	c 0	r 22
---			
list files	clear	c 0	r 22
---			
disk free	clear	c 0	r 22
---			
hostname	hostname ---	c 0	r 22
list drives	clear	c 0	r 22
---			
mount	POU_SplitArray.arr[INDEX] 1 --- 2 --- 3 --- 4 --- 5 --- 6 --- 7 --- 8 --- 9 --- 10 --- 11 ---		
mount	mount ---	c 0	r 22
USB stick can be removed.			

acc1 rights Set if in settings 19. Path has been changed.

acc2 rights Set if in settings 19. Path has been changed.

List directory

Show free storage

Show host name


Describe USB stick:  
ever in this order: Insert  
stick  
1. list drives  
2. Select drive (USB stick)  
3. mount  
4. write  
5. unmount  
6. remove the stick

## 20. USB



acc 1	chgrp fliegl -R /media/sdcard/data/ ---	c 0	r 22
acc 2	chmod g+s -R /media/sdcard/data/ ---	c 0	r 22
acc 3	chmod 775 -R /media/sdcard/data/ ---	c 0	r 22
---			
list files	clear	c 0	r 22
---			

## 6. Leak test



## 6. Leak test

A leak test can be carried out under "Tightness test." The tightness test is carried out at the factory.

## 1. Warning counter

The interface displays six rows of error information:

Error	Level max reached	filling	0
Error	Time reached	filling	0
Error	Level max reached	Drying	0
Error	Time reached	Drying	0
Error	Level max reached	emptying	0
Error	Time reached	emptying	0

Below the table are two yellow navigation buttons: a left arrow and a house icon.

## 1. Warning counter

The alarm counter counts the accumulated warnings  
Where 6 alarms have occurred, a single alarm can be acknowledged  
and the alarm counter is reset  
The various warnings listed under the alarm counter are intended to  
alert the operator that he is causing the problem check for the  
warnings, especially if they lead to a "Counter-Alarm" (alarm after 6  
warnings as described above).

## 2. User administration

The interface includes three red buttons for Log In, Sign out, and Change Password, each with a black circular icon. To the right is a user icon with a plus sign. Below these are two black rectangular boxes containing "Current username" and "Current user level 0". At the bottom are two yellow navigation buttons: a left arrow and a house icon.

## 2. User administration

User Management is not used at the moment.

## 3. step chain J1939 Manager


The interface features a grid of SFC functions:

SFCInit	SFCErrorStep:	SFCTrans
SFCReset	SFCErrorPOU:	SFCTip
SFCError	SFCQuitError	SFCTipMode
SFCEnableLimit	SFCPause	

Below the grid are two white boxes: SFCCurrentStep:ID\_6329\_STEP\_Read\_LoadcellD and SFCCurrentStepTranslated: STEP Read LoadcellB. At the bottom are two yellow navigation buttons: a left arrow and a house icon.

## 3. step chain J1939 Manager

Used to control the load cells. Is not relevant for the operator.




## 4. J1939 manager

## 4. J1939 manager

Used to control the load cells. Is not relevant for the operator.


## 5. Flick



## 5. Flick

Under "Flick" a functional test of the touch panel can be carried out.


## 6. Touches




## 6. Touches

Under "Touches" a functional test of the touch panel can be carried out.

## 7. step user level



## 7. step user level



## 8. User level

Userlevel shows the currently used userlevel and the remaining time.

## 9. inputs

EL1008 SPS3	
PV.TRD.filling pump.x Fault	
PV.TRD.filling pump.x feedback	
PV.TRD.emptying pump.x Fault	
PV.TRD.emptying pump.x feedback	
PV.TRD x Buffer level	
PV.TRD emptying valve x Feedback Closed	
PV.TRD filling valve.x Feedback closed	
PV.TRD.emptying valve.x Feedback Open	

EL1008 SPS4	
PV.TRD.filling valve.x Feedback Open	
PV.TRD filling valve external.x feedback Open	
PV.TRD.emptying valve Extern.x Feedback Open	
PV.TRD x level min	
PV.TRD.x filling level Max	
PV.TRD.Sch.x Overfill protection	
PV.TRD.Sch.x Emergency stop feedback	

## 9. inputs

Displays the occupied inputs.

EL1008 SPS3	
PV.TRD.filling pump.x Fault	
PV.TRD.filling pump.x feedback	
PV.TRD.emptying pump.x Fault	
PV.TRD.emptying pump.x feedback	
PV.TRD x Buffer level	
PV.TRD.emptying valve.x Feedback Closed	
PV.TRD.filling valve.x Feedback closed	
PV.TRD.emptying valve.x Feedback Open	

EL1008 SPS4	
PV.TRD.filling valve.x Feedback Open	
PV.TRD filling valve external.x feedback Open	
PV.TRD.emptying valve Extern.x Feedback Open	
PV.TRD x level min	
PV.TRD.x filling level Max	
PV.TRD.Sch.x Overfill protection	
PV.TRD.Sch.x Emergency stop feedback	

EL1008 SPS5	
PV.TRD.flushing.pump.x OK	
PV.TRD.flushing pump.x feedback	


## 10. sequence blinker



SFCInit	SFCErrorStep:	SFCTrans
SFCReset	SFCErrorPOU:	SFCTip
SFCError	SFCQuitError	SFCTipMode
SFCEnableLimit	SFCPause	
SFCCurrentStep:ID_11_Aus		
SFCCurrentStepTranslated: Off		
Off		

## 10. sequence blinker

## 11. blinker



## 11. blinker

Visualization of the lamp on the control cabinet. Fault lamp.

Blink rhythm:


1s ON / 1s OFF: Emergency operation

Leed (permanently ON): FAULT or PLANT STOP

3s ON / 3s OFF: \$Pending pending

Temporary OFF: \$T No warning, no fault

## 12. sequence expiration




## 12. sequence expiration

Allows the user to intervene in the sequencer's flow.

For more information, see:

[https://help.codesys.com/webapp/cds/sfc/sfc\\_flags;product=codeSYS;version=3.5.13.0](https://help.codesys.com/webapp/cds/sfc/sfc_flags;product=codeSYS;version=3.5.13.0)

## 13. Sequence operating mode




## 13. Sequence operating mode

Allows the user to intervene in the sequencer's flow.


For more information, see:

[https://help.codesys.com/webapp/cds/sfc/sfc\\_flags;product=codeSYS;version=3.5.13.0](https://help.codesys.com/webapp/cds/sfc/sfc_flags;product=codeSYS;version=3.5.13.0)




## 14. Device Reader

Represents the unlocked licenses. Green = License unlocked.



## alarms




## Alarms detail

Time how many alarms per group are active.


S	report	State	active	Inactive	Approved
0		Fault inverter drum	Normal	26.02.2019 21:19:55	26.02.2019 21:20:04
1		Fault i550 Ethercat	Normal	26.02.2019 21:19:41	26.02.2019 21:19:45
2		overfill protection	Normal	26.02.2019 21:19:41	26.02.2019 21:19:45
3		Fault EL2008 PLC6	Normal	26.02.2019 21:19:41	26.02.2019 21:19:45
4		Fault EL2008 SPS7	Normal	26.02.2019 21:19:41	26.02.2019 21:19:45
5		Fault EL3202 SPS8	Normal	26.02.2019 21:19:41	26.02.2019 21:19:45
6		Fault EL1008 PLC4	Normal	26.02.2019 21:19:41	26.02.2019 21:19:45
7		Fault EL1008 SPS5	Normal	26.02.2019 21:19:41	26.02.2019 21:19:45
8		Fault EK1100 PLC2	Normal	26.02.2019 21:19:41	26.02.2019 21:19:45
9		Fault EL1008 PLC3	Normal	26.02.2019 21:19:41	26.02.2019 21:19:45
10		Emergency stop	Normal	26.02.2019 21:19:41	26.02.2019 21:19:45
11		Undertemperature limit	Normal	26.02.2019 09:39:01	26.02.2019 09:39:57

## Alarms history

### 18. sequence leak test




### 18. sequence leak test




## Filling

Shows graphically whether there is an error in the step sequence  
This shows the weight, the elapsed time and the minimum and maximum time.  
ext is a graphic representation of the filling quantity




## Drying

Shows graphically whether there is an error in the step sequence  
This shows the weight, the elapsed time and the minimum and maximum time.  
ext is a graphic representation of the filling quantity



## emptying

Shows graphically whether there is an error in the step sequence  
This shows the weight, the elapsed time and the minimum and maximum time.  
ext is a graphic representation of the filling quantity








# step


Time the entire step chain.


The currently active step is displayed in color. Under points 2 and 3, the sub-steps evaporation and flushing are accessible, below 1, the total chain erreichbar.


# tPOU sequencer SFC VISU


Time the entire step chain.  
The currently active step is displayed in color.


















# Mflush

Sub-step rinse




# Drying

Sub-step evaporation




# J1939 Manager Request SI

shows the query of the load cells in succession




# operation mode

Run of the operating mode including emergency operation.




# blinker

blinker expiration




# Leakage test

Procedure of the leak test



# User level

Expiry of the user level



# **blank page**


# dialogues

Time entry form

T#0ms

0h	0m	0s	0ms	
+10m	+1m	+10s	+1s	+100ms
-10m	-1m	-10s	-1s	-100ms

CLEAR    ESC    OK



Dialog for maintenance counter

LTIME#0ns

0d	0h	0m				
+365d	+1d	+1h	+1m	+10s	+1s	+100ms
-365d	-1d	-1h	-1m	-10s	-1s	-100ms

CLEAR    ESC    OK

Dialogue for big times like the hour meter

Change user level

\*\*\*\*

standard users

ESC    OK

Master user    Administrator    Super administrator

Login

# Alarm texts of the alarm group gError

Alarm groups GError ACK, GError SFC and Warning Start conditions:

O Any error from these two groups triggers the operation mode "Emergency operation". After expiry of the monitoring time for emergency operation, the control system switches to the "RESTART" operating mode

When rectifying and acknowledging errors occur during the emergency control period, the control system switches to the "Auto" operating mode.  
o restart of the "Auto "(Except warning start conditions)

100	Emergency stop
101	Fault EK1100 PLC2
102	Fault EL1008 PLC3
103	Fault EL1008 PLC4
104	Fault EL1008 SPS5
105	Fault EL2008 PLC6
106	Fault EL2008 SPS7
107	Fault EL3202 SPS8
108	Fault i550 Ethercat
109	overfill protection

# Alarm texts of the alarm group GErrorSFC

200	ERROR filling pump on timeout
201	ERROR filling pump Off Timeout
202	ERROR emptying pump on timeout
203	ERROR emptying pump Off Timeout

# Alarm texts of the alarm group

## GError ACK

301	Load cell 1 TEMPUR
302	Load cell 1 TEMPOR
303	Load cell 1 ECOMUR
304	Load cell 1 ECOMOR
305	Load cell 1 CRAWUR
306	Load cell 1 CRAWOR
307	Load cell 1 LCINTEG
308	Load cell 2 TEMPUR
309	Load cell 2 TEMPOR
310	Load cell 2 ECOMUR
311	Load cell 2 ECOMOR
312	Load cell 2 CRAWUR
313	Load cell 2 CRAWOR
314	Load Cell 2 LCINTEG
315	Load cell 3 TEMPUR
316	Load cell 3 TEMPOR
317	Load cell 3 ECOMUR
318	Load cell 3 ECOMOR
319	Load cell 3 CRAWUR
320	Load cell 3 CRAWOR
321	Load cell 3 LCINTEG
322	Load cell 4 TEMPUR
323	Load cell 4 TEMPOR
324	Load cell 4 ECOMUR
325	Load cell 4 ECOMOR
326	Load cell 4 CRAWUR
327	Load cell 4 CRAWOR
328	Load Cell 4 LCINTEG
329	Fault Connection Inverter Drum
330	Fault Fan 1
331	Fault fan 2
332	Maintenance counter 3 expired
333	Fault inverter drum
334	Fault load cell 1 no connection
335	Fault load cell 2 no connection
336	Fault load cell 3 no connection
337	Fault load cell 4 no connection
338	Fault scrubber air temperature
339	ERROR flushing pump
340	Filling pump motor protection switch faulty
341	Emptying pump motor protection switch faulty
342	Fault heating pump
343	Fault heat quantity counter
344	Fault release from scrubber
345	Fault scrubber collective malfunction

# Alarm texts of the alarm group

## GWarning

Alarm group Warning and Warning SFC:  
Es only one entry is made in the alarm list, the system does not react.

401	Undertemperature limit reached!
402	Maintenance counter 1 expired
403	Maintenance counter 2 expired
404	Plant stop from operating mode
405	PT100 supply air temperature sensor wire break
408	PT100 supply air temperature sensor overrange
409	PT100 supply air temperature sensor underrange
410	PT100 heating system return sensor wire break
413	PT100 heating system return sensor overrunning
414	PT100 heating system return sensor underrange

# Alarm texts of the alarm group GWarningSFC

500	ERROR Filling valve open Timeout
501	ERROR Filling open External Timeout
502	ERROR filling level Max reached
503	ERROR filling Time reached
504	ERROR Filling External close Timeout
505	ERROR Filling valve close Timeout
506	ERROR Drying time reached
507	ERROR Emptying valve open Timeout
508	ERROR Emptying External open Timeout
509	ERROR level reached min
510	ERROR emptying Time reached
511	ERROR Emptying External close Timeout
512	ERROR Emptying valve close Timeout
513	ERROR Flushing pump on timeout
514	ERROR Flushing pump Off Timeout
515	ERROR drying Level Min reached
516	ERROR filling level Max reached filling counter
517	ERROR filling time reached counter
518	ERROR drying time reached counter
519	ERROR fill level Min reached drying counter
520	ERROR level Min reached emptying counter
521	ERROR time reached emptying counter

# **Alarm texts of the alarm group GWarningStartConditions**

601	ERROR Start Condition Filling valve not Closed
602	ERROR Start condition Emptying valve not Closed
603	ERROR start condition Filling valve open
604	ERROR Start Condition Filling valve Open
605	ERROR start condition Buffer level
606	ERROR start condition flushing pump

## 1. curves



## 1. curves

Curves graphically displays the recorded values of the listed sensors or loads.

1. curves

2. Min Max Timestamps

4. New Data Written



## 1. curves



## 2. Min Max Timestamps



## 2. Min Max Timestamps

Curves graphically displays the recorded values of the listed sensors or loads.

	Year / Month / Day	Hour / Minute / Second / Millisecond / Microsecond
lMinTimestamp = 1548581991427000	= 2019 1 27	9 39 51 427 0
lMaxTimestamp = 1551211665167000	= 2019 2 26	20 7 45 167 0
eError = 0		



-



## 4. New Data Written




## 4. New Data Written

Last write = 0 rows	Year / Month / Day	Hour / Minute / Second / Millisecond / Microsecond
TS from = 0	= 0 0 0	0 0 0 0 0
TS to = 0	= 0 0 0	0 0 0 0 0



...



# automatic Sequencer

Off	Start Drying Log
init	MDrying
Filling	Wait for Drying
Drying	Start Emptying log
emptying	Empty valve open
alarm	waiting period end of cycle
automatic	Histogram Overrun Correction Drying
hand	OK emptying valve open
Test start conditions A	ERROR Emptying valve open Timeout
Test start conditions B	Empty valve open external
Test start conditions C	OK emptying valve open external
Test start conditions D	ERROR Emptying valve open external timeout
Test start conditions E	Empty pump on
Test start conditions F	OK emptying pump on
OK No alarm	ERROR Empty pump on timeout
OK Start condition Filling valve Closed	OK emptying pump is running
ERROR Start Condition Filling valve not Closed	OK emptying
OK Start condition Emptying valve Closed	ERROR filling level Min reached empying
ERROR Start condition Empyng valve NOT Closed	ERROR Time reached Emptying
OK Start condition Filling valve NOT open	Empty pump off
ERROR start condition filling valve open	OK emptying pump off
OK Start condition Emptying valve NOT open	ERROR Empty Pump Off Timeout
ERROR Start Condition Emptying valve Open	Empty pump break caster
OK Start condition Buffer level	Empty valve close external
ERROR start condition buffer level	OK emptying valve closed external
OK start condition flushing pump	ERROR Emptying valve close external timeout
ERROR start condition Flushingl pump	Empty valve close
Fan off	OK emptying valve closed
Fan on	ERROR Emptying valve close Timeout
OK start conditionsfilled	Wait for emptying
StartFilling Log	Histogram Overrun Correction Emptying
Filling Valve open	End of cycle Log
OK filling valve open	Finish detoxifying B
ERROR Filling valve open Timeout	flushing pump on
Filling Valve open external	OK flushing pump on
OK filling valve On external	ERROR Flushing pump On timeout
ERROR Fillling valve open External Timeout	OK flushing pump is running
Filling pump on	flush
OK filling pump On	OK flushing
ERROR Fill pump on timeout	flushing pump off
OK filling pump is running	OK flushing pump Off
OK Filling	ERROR Flushing pump Off Timeout
Filling pump off	flushing break caster
OK filling pump off	OK Drying
Filling pump break caster	ERROR Level Min reached drying
Filling valve close external	ERROR time reached Drying
OK filling valve To external	Set Standard user
filling valve close	standard users
OK filling valve closed	Administrator
Wait for filling	Master user
Histogram Overrun Correction Filling	Leakage test running
ERROR filling level Max reaches Filling	Leakage test completed
ERROR Time reached Filling	Leakage test not necessary
ERROR Fill Pump Off Timeout	Emergency run caster ramp C
ERROR Filling valve close external timeout	hand break
ERROR Filling valve close Timeout	Mauto
Mflush	auto
	Emergency running start conditions
	Emergency running

# automatic Sequencer

## State

Emergency run caster ramp A  
Emergency run caster ramp B  
stop system  
INIT ACT step chain  
STEP Read LoadcellA  
STEP Read LoadcellB  
STEP Read LoadcellC  
STEP Read LoadcellD  
blinker  
Lighting system stop  
Luminous X Fault  
slowly blinking  
Off before auto  
ERROR filling level Max reached  
ERROR level reaches min

Start filling

Start drying

Start emptying

End of cycle

## Logger

End\_Cycle\_Time

End cycle weight  
kg

End of cycle heat quantity  
kWh

Start\_emptying\_Time

Start emptying weight  
kg

Start emptying heat quantity  
kWh

Start\_Filling\_Time

Start filling weight  
kg

Start filling heat quantity  
kWh

Start\_Drying\_Time

Start drying weight  
kg

Start drying of heat  
kWh

ID

Timestamp

---

Total amount of heat  
kWh

Sum of evaporated weight in kg

Total\_Time


Kwh per kg

Operating mode Current Step

Sequencer Current Step

State

# Datalogger



The data logger outputs data in 3 formats: \$ R \$ N \$ R \$ N1. HTML \$ R \$ N2. XML \$ R \$ N3. CSV \$ R \$ N \$ R \$ N \$ R \$ Note: CSV is output with the following settings: \$ R \$ NDecimal separator: (Dot) \$ R \$ NFseparator: (Semicolon) \$ R \$ NFeldlimiter: \$ "Quotes"

Select these settings in the Windows Control Panel

Use of the logged data in .csv format (Excel export):

For the error-free display of the logged data in .csv format (eg Excel), countries that use "comma" as the decimal separator (Example: 1.000,00) requires the decimal separator to be changed to "dot" (example: 1.000.00).


Because the RondoDry standard control is the same for all countries, the decimal separator of "comma" must be in the following countries "Point" will be changed to:

\$Albania, Andorra, Argentina, Belgium, Bolivia, Brazil, Bulgaria, Chile, Denmark, Germany, Ecuador, Estonia, Faroe Islands, Finland, France, Georgia, Greece, Greenland, Indonesia, Iceland, Italy , Colombia, Kosovo, Croatia, Cuba, Latvia, Lithuania, Luxembourg, Macedonia, Moldova, Netherlands, Norway, Austria, Paraguay, Peru, Poland, Portugal, Romania, Russia, Sweden, Serbia, Zimbabwe, Slovakia, Slovenia, Spain, South Africa , Czech Republic, Turkey, Ukraine, Hungary, Uruguay, Venezuela, Belarus

When using Windows as the operating system, the changeover occurs as follows:

Click "Start" (the round Windows icon on the lower left) and then "Control Panel."

Click "Region and Language" (Windows 10: "Language").



In the "Region and Language" menu, please click on "Additional Settings". In the menu "Customize Format", the decimal separator must be "dot" (.) And the symbol for the grouping of numbers must be "comma" (,). The entry is to be confirmed with "Accept" and "OK".

